


32. Risk of damage

! Always keep close the hatch windows shown below to avoid damage of hatches by rope of Genoa and boom.



! In reverse gear when the yacht is going astern, with the propeller "walking" the stern to starboard (right side).

! Due to the overload of coastal sea, please book in advance Marinas, Restaurants and buoys berthing for your restful sleep on the yachts:

- a. <https://my-sea.com/en>
- b. <https://book.aci-club.hr/>

! Check daily forecast on:

- <http://meteo.hr>

- https://www.windfinder.com/weatherforecast/poljica_trogir

(only 3 days superforecast page)

- <https://www.windy.com/-Wind-gusts-gust>

! Be very carefully with the sheet, mooring line in order to avoid winding on the engine and bowthruster propeller.

Spare engine propeller located under the saloon seat.