

28.Refrigeration

The refrigerator on this boat is powered with 12v. It is designed to run 4hrs continuous without charging of service batteries then you can switch-off the unit and it is keep the low temperature some hours more to avoid of service batteries is empty . Refrigerator has a small freezer compartment. There are two things you should do:

1.Firstly, keep your batteries charged. If the level goes below 12v the system will malfunction. See the section 25 for charging instructions.

2.Secondly, do not chip at the ice or use any other sharp items in the fridge. If something is frozen to the fridge do not force it away. Warm water on it if you need to melt it away.

There is a thermostat in the fridge. It is a white dial with numbers on it going from 1-7. Putting 7 at the apex of the dial is the coldest setting. Keep it on this setting until it is too cold. Then you can turn the system down or off if you wish.

