


29 . BOW THRUSTER

bowthruster located in bow locker under the plastic hetch.



Bowthruster automatic switch

Fuse