27.Refrigeration

The system on this boat is an upgraded 12v refrigerator. This system is designed to run 4hrs continuous without charging of service bataries then the units off they keep the low temperature some hours more. To ensure that it does not fail there are two things you should do.



1.Firstly, keep your batteries charged and check voltage . If the level goes below 12.2v the refrigeration must be off. Refer to section 24 for charging instructions and http://eurospectra.com/wp-content/uploads/2022/06/Power-consumption-on-board..pdf

2.Secondly, do not chip at the ice or use any other sharp items in the fridge. If something is frozen to the fridge do not force it away. Warm water on it if you need to melt it away.