

2. The 12 volt panel

Use the up and down buttons to toggle through your water tank gauge and your battery voltage. The following functions are available on the 12v panel.

Navigation knob from left to right and from top to low row :

Anchor light	Deck light	Navigation light
Engine light	free	Compass light
Instruments, Autopilot, Plotter	free	free

Middle row functions from left to right:

Fridges	free	Water pump
Shower dry pump	Bilge pump	Boethruster bilg pump
Anchor windlass	free	free

Bottom row functions from left to right:

Saloon light	Cabins light	free
Bluetooth	free	free
free	free	free

