

## 19. Heating

Turn on the heating by pressing the top button on the remote control, after which the fuel pump will make a click every second.

After 5 minutes, the heating will begin to work.



Turn off the heating by pressing the top button on the remote control.

## 20. WIFI Internet

Mobile access point is over the 12v control panel must always be included in electricity for internet access.



Use the net name and passport specified in boat documents.