

29.BOW THRUSTER



Bowthruster button



Bowthruster switch



Fuse of bowthruster located in space under the bed of bow cabin.

