

32. Risk of damage

! Always keep close the hatch windows shown below to avoid damage of hatches by rope of Genoa and boom.



! In reverse gear when the yacht is going astern, with the propeller "walking" the stern to starboard (right side).

! Due to the overload of coastal sea , please book in advance Marinas, Restaurants and buoys parking for your restful sleep on the yachts:

- a. <https://my-sea.com/en>
- b. <https://book.aci-club.hr/>

- https://meteo.hr/prognoze_e.php?section=prognoze_specp¶m=jadran

- <https://www.windy.com/-Wind-gusts-gust?gust,43.196,15.691,8,m:eREagCc>

! Be very carefully with the sheet, mooring line in order to avoid winding on the engine and bowthruster propeller.

Spare engine propeller located under the saloon seat.