


230V SYSTEM

The boat is equipped with a 230 V electrical circuit. The shore socket is located in the cockpit. In addition to the battery charger, the circuit also comprises sockets for 230 V consumers.

Main switches is located in port aft cabin behind the wall hatch. When the boat is connected to an external 230 V supply then red light is on.



Main switches



WARNING: Before connecting the cable on the shore, connect it to the boat first.

Disconnect the cable after use. First switch off the main switch in the boat, then disconnect the cable on the shore and last, disconnect it on the boat.

Do not soak the catches of the cable in water.