

2. The 12 volt panel

Use the up and down buttons to toggle through your water, waste, fuel tanks gauge and your starter, bowthruster, engine batteries voltage. The following functions are available on the 12v panel.

Left side buttons
functions from top to
down:

Cabin lights

Navigation lights

Anchor light

Musthead light

Deck light

Tri-colour light not in
use

Fridge

Outlets 12v/USB



Right side buttons
functions from top
to down:

Instruments

VHF

GPS

Autopilot

Fresh water pump

Shower pump

Servise main battery switch on skipper control panel



Engine main battery switch under the bottom step

